

TICO PRO-SPOTTER				
S/N:		BATTERY & WIRING - QSB, 2 BATTERIES, ALARM		71717
ITEM	PART #	QTY/M	DESCRIPTION	TASK/REV
	71385-B1		BATTERY & WIRING - 2 BATTERIES	
1	61708	1	TRIPLE BATTERY BOX	
2	82462	4	BOLT, HEX, 1/2-13 X 3 LG	
3	85027	4	LOCKNUT, NYLOCK, 1/2-13	
4	85093	8	WASHER, FLAT, HARD, 1/2	
5	40193	2	BATTERY, 12V	
6	20075	2	BATTERY HOLD DOWN	
7	20012	4	ASSEMBLY, J-BOLT	
8	20077	4	COUPLING, EYE, 1/4-20	
9	20012-4	4	WASHER, .25 x 1.25 x .88, GRAY PLASTIC	
10	85089	8	WASHER, FLAT, HARD, 1/4	
11	82359	4	BOLT, HEX 1/4-20 X 3/4 LG	
12	90120	3	GROMMET	
13	12070	1	BRACKET, BATTERY STOP	
14	82371	1	BOLT, HEX, 5/16-18 X 1" LG	
15	85024	1	NUT, NYLOCK, 5/16-18	
16	85090	2	WASHER, FLAT, HARD, 5/16	
17	90957	2	TERMINAL STRIP	
18	40210-2	1	RUBBER MAT, BATTERY BOX	
19	40198	1	ALARM, BACKUP	
20	85023	2	LOCKNUT, NYLOCK, 1/4-20	
21	90207	1	HORN, ELECTRIC	
22	85134	1	LOCKWASHER, 5/16	
23	85002	2	NUT, HEX, 5/16-18	
24	61675	1	CHASSIS PDC	
25	82383	2	BOLT, HEX, 3/8-16 X 1 1/4 LG	
26	85135	2	LOCKWASHER, 3/8	
27	85091	4	WASHER, FLAT, HARD, 3/8	
28	85014	1	NUT, HEX, 3/8-16	
29	91521	1	COVER, PDC PANEL	
30	61597	1	SPACER	
NOT SHOWN	91021	1	FUSE, 5A - F17	
NOT SHOWN	91023	3	FUSE, 10A - F4/F15/F19	
NOT SHOWN	91025	10	FUSE, 20A - F2/F3/F5/F7/F8/F9/F10/F14/F18/F20	
NOT SHOWN	91027	1	FUSE, 30A - F6	
REV	DATE	BY		SHEET
				1 OF 2

